


# Quick Setup with Wanco® Wireless Arrow Boards


**NOTE:** When shipped from the factory, the wireless controller and arrow board are paired and ready for installation. Skip steps 3 through 7 unless pairing is required.

1




If not already installed, install the Wanco wireless arrow board according to the instructions provided in the arrow board owner's manual.

2




If not already installed, install the controller inside truck cab, including mounting bracket and connecting to power.

3




Ensure power is on for the arrow board.

4




Ensure power is on for the controller, then press and hold the on/off button for 3 seconds to turn the controller on.

5



Use the touchscreen to set the controller to PAIRING mode. Press the PAIR button to view the pairing screen. Follow the on-screen instructions.

6




When prompted, press and hold the pairing button on the arrow board; the arrow board lights will flash quickly while holding it. Release the button when the flashing changes to a slower pattern.

7



A message on the touchscreen indicates when pairing is successful.


8



Use touchscreen to verify the correct power tilt-frame is selected. The choices are:

- 90° tilt-frame
- 180° tilt-frame
- NONE (for third-party, manual tilt, or no frame)

9



Disable one or more display patterns, if desired.

TOUCHSCREEN CONTROLLER  
**System Menus**

**Main**

- Display Patterns
- Status
- Setup
- Tilt

**Display patterns (12+blank)**

- Right arrow
- Left arrow
- Right stem arrow
- Left stem arrow
- Right walking arrow
- Left walking arrow
- Right chevron arrow
- Left chevron arrow
- Double arrow
- Alternating diamond
- Four corner
- Bar
- Blank

**Display patterns (7+blank)**

- Right arrow
- Left arrow
- Right stem arrow
- Left stem arrow
- Double arrow
- Bar
- Four corner
- Blank

**Display patterns (5+blank)**

- Right arrow
- Left arrow
- Double arrow
- Bar
- Four corner
- Blank

**Status**

- System Info
- Alarms
- Voltage

**Setup**

- (Controller)
- Pair
- Night/Day
- Options
  - Controller
    - Patterns (disable/enable)
    - Display
      - Standard
      - Single screen
    - Calibrate touchscreen
  - Arrow board system
    - Electric tilt-frame
      - Frame type
        - 90° tilt frame
        - 180° tilt frame
        - None
      - Tilt motion
        - Auto stop
        - Manual stop
    - Calibrate compass
  - System reset
    - Confirm/cancel
  - Maintenance mode
    - All lights on
    - All lights off
    - Fault lights off
- (Arrow board)
- Bright
- Dim
- Auto-brightness

**Tilt (90°)**

- Up
- Down
- Stop

**Tilt (180°)**

- Right
- Neutral
- Left
- Stop

For complete instructions for using the controller, see the  
 Touchscreen Controller for Wanco® Wireless Arrow Boards User's Manual.